

# Zero7

## FEATURES

- The Zero7 is a modular, high performance, ergonomic chair that is capable of fitting into any workspace. Easily paired with our Best of NeoCon award winning Zero9 to complete any environment.
- The backrest is available in three different unique options; scratchproof polypropylene, nylon mesh and with an upholstered panel, all come with standard adjustable lumbar support.
- Scratchproof polypropylene backrest comes with lumbar support in soft anthracite color polyurethane.
- Mesh back version is made of a black nylon frame and covered with nylon mesh.
- Upholstered panel is padded with polyurethane foam on a polypropylene back.
- The seat features a waterfall front edge design to relieve pressure behind the legs. Padded with fire-retardant CFC polyurethane foam, with a polypropylene internal seat, reinforced with steel square tubular bars; the seat pan is made of shockproof and scratchproof polypropylene to match the backrest.
- 4D adjustable T-arms (height, and width adjustment, with pivot and sliding arm pad) have a nylon frame, in black, with comfort polyurethane arm pads.
- Fixed polypropylene armrests come in the same color as the mesh or polypropylene backrest.
- The Zero7 comes standard with a synchro tilting mechanism which uses a multi-block system with several locking position.
- Swivel and seat height adjustment is obtained by a pneumatic gas cylinder
- 5-Star, nylon base reinforced with fiberglass in black.
- Carpet twin wheel-casters.
- Meets safety and performance standards of ANSI/BIFMA x 5.1-2010.
- Available in all standard Borgo fabric, leather, vinyl, as well as COM & COL.

## OPTIONS

- Upholstered Polypropylene Back Panel\*: Black, White, & Gray
- Mesh Back\*: Black, White, & Gray.
- Polypropylene Back\*: Black, White, & Gray.
- Synchro control with sliding seat pan.
- Simple height adjustment only control.
- Mirco-Springs Comfort Seat with stitch seams, puts tiny springs inside beneath the seat cushion offering optimal support and comfort.
- 5-Star chrome-plated base.
- Various casters and pneumatic gas cylinder options available.

\*Polypropylene seat pan and fixed arms will always match the color mesh or polypropylene back rest.



Micro-Spring Comfort Seat



**Zero7**  
design Giovanni Baccolini



**7213** Adjustable Arms  
**7219** Fixed Arms  
**7211** Armless  
High Back



**7233** Adjustable Arms  
**7239** Fixed Arms  
**7231** Armless  
Mid Back



**7233S** Adjustable Arms  
**7239S** Fixed Arms  
**7231S** Armless  
Drafting Stool

<b>Max Height:</b> 42.5-47.5"	1080-1210 mm	37.5-42.25"	950-1080 mm	44.25-54.25"	1125-1380 mm
<b>Max Width:</b> 24.5"	620 mm	24.5"	620 mm	25.5"	650 mm
<b>Armless Width:</b> 23.5"	600 mm	23.5"	600 mm	23.5"	600 mm
<b>Max Depth:</b> 21.25"	540 mm	21.25"	540 mm	21.25"	540 mm
<b>Adj Arm H:</b> 24.5-31.5"	622-800 mm	24.5-31.5"	622-800 mm	31.5-46.5"	800-1180 mm
<b>Fixed Arm H:</b> 24.75-32"	630-815 mm	24.75-32"	630-815 mm	32.25-42.5"	820-1080 mm
<b>Back Height:</b> 25.5"	650 mm	20.5"	520 mm	20.5"	520 mm
<b>Seat Height:</b> 16.5-22"	430-560 mm	16.5-22"	430-560 mm	20.5-32.5"	520-825 mm
<b>Seat Width:</b> 20"	510 mm	20"	510 mm	20"	510 mm
<b>Seat Depth:</b> 17"	430 mm	17"	430 mm	17"	430 mm
<b>Wt/Chair:</b> 43 lbs.	19 kg	39 lbs.	18 kg	44 lbs.	20 kg
<b>Volume:</b> 19 ft <sup>3</sup>	0.54 m <sup>3</sup>	19 ft <sup>3</sup>	0.54 m <sup>3</sup>	19 ft <sup>3</sup>	0.53 m <sup>3</sup>
<b>COM Fabric:</b> 1.5 yd	1.38 m	1.25 yd	1.0 m	1.25 yd	1.0 m
<b>Per Carton:</b> 1		2		1	



### EVER-CHANGING CHAIR

The Zero7 can wear many hats, the mesh back is ideal for a user looking for flexible support and air flow, while the polypropylene back is perfect for a user who likes to get messy and the upholstered back is suited for a more traditional comfort. The Zero7 doesn't stop there, with a multitude of arm, mechanism, and seat options further allow versatility to the line. The Zero7 has inspired the award winning Zero9, enhancing the functionality of the line.



### A CHAIR TO INSPIRE

The idea of the Zero7 is to allow the user to design a chair based on their needs, wants and desires. Today's modern office chair must be a tool to help inspire, motivate and support the user.



**Zero7**